

JDLink™ SETUP GUIDE



CLICK THE ARROW TO GET STARTED



Table of Contents

[Cover Page](#)

[Table of Contents](#)

[Terminology](#)

[JDLink™ Required Components](#)

[Dealer Responsibilities](#)

[Dealer Account Setup and Access](#)

[Operations Center Customer Account Setup](#)

[Operations Center Customer Account Setup: Customer Org.](#)

[Operations Center Customer Account Setup: Partner](#)

[Activation of All JDLink™ Hardware](#)

[Manage Subscriptions: Factory Install](#)

[Manage Subscriptions: Field Install](#)

[Activation Process: Factory Installed, Non-Factory Activated Subscriptions](#)

[Activation Process: Field Kit Activations](#)

[Activation Process: Non-Factory Activated Subscriptions & Field Kits](#)

[Hardware Installation General Information](#)

[Install Hardware: Ultimate Field Installation](#)

[Install Hardware: Field Installation \(Select, Locate, Express\)](#)



Table of Contents

[Terminal Transfers](#)

[Terminal Transfers: Operations Center](#)

[Terminal Transfers: JDLink™](#)

[Resources](#)



Terminology

Account	Unique customer profile including contact information, password/challenge question, username
Account Management	The enabling processes/system from John Deere that give customers and dealers tools to help carry out data management.
Admin	Authorized to view and change settings, landmarks, driving directions, Org preferences, manage access to machine information, establish 3rd party access, and add/delete/modify users and their roles.
Agronomic Specialist	Authorized to view and manage all production and agronomic data (MyJohnDeere only). Able to view and request permissions access only.
Customer Profile Support	Authorized to add, edit, and manage customer profiles in StellarSupport™.
Customer Support	Authorized to support customer organizations if granted- add, edit, and manage customer Staff. Ability to retrieve customer terminals if granted. Manage pre-delivery setup process for dealer-search, edit, and add new profiles, manages relationship types and sharing permissions relationships.
JDLINK™ Factory Installed	<ul style="list-style-type: none"> <input type="checkbox"/> JDLINK™ is configured during machine order. <input type="checkbox"/> Installed and enabled at the Platform factory <input type="checkbox"/> JDLINK™ Ultimate comes in base dependent on how the machine was configured.



Terminology

JDLink™ Field Installed	<ul style="list-style-type: none"><input type="checkbox"/> Installed and enabled on machine by the dealer<input type="checkbox"/> Select or Ultimate depending on machine type field kit configured
JDLink™ Select	Solution that fits any make/model of equipment, including older John Deere and non-John Deere equipment.
JDLink™ Ultimate	Solution specific to John Deere machines providing data through direct communication with on-board machine controllers.
Organization (Org)	Grouping structure of users, machines, data, preferences for a customer in JDLink™, Field Connect™, or MyJohnDeere.
Org-to-Org Permission	Your customer gives you or another “third party” permission to support his/her organization to perform certain functions.
Permissions	<p>Data access and service capabilities shared between Organizations.</p> <p><i>Passive:</i> Default to support dealer-customer relationships as a result of a dealer completing partner setup. Partner setup means you as a dealer request permissions, set relationship type and trigger validation for the customer. It doesn't require active customer approval to start.</p> <p><i>Active:</i> Require customer approval before the setup is completed.</p>



Terminology

Relationship Type	Agreement between dealer and customer upon how to manage customer's organization
Solution	An end-to-end offering that begins with understanding a customer's business need or goal and the value provided is realized through achieving the desired results. A solution may include a combination of equipment, technology, service, support and value-added service(s).
Validated	Account state when email, password, and challenge question are confirmed to be associated with customer.



JDLink™ Required Components



1. Modular Telematics Gateway (MTG)

- ❑ MTG has to have the latest software version

2. Appropriate Wiring Harness

3. Computer or Mobile Device with Internet Access

4. Valid JDLink™ Subscription

Dealer Responsibilities

- Install JDLINK™ Hardware (Field Install)
- Manage Customer Subscriptions
- Transfer Terminals (JDLINK™ or Operations Center)
 - Transfer Subscriptions
 - Add Replacement Terminals
- Setup Customer Partnership (Operations Center)

To complete these responsibilities a dealer must have the following roles:

- Customer Support Role
- Admin or Manager Role (JDLINK™ only)
Note: The subscriber role cannot transfer terminals

These roles are setup in Role Based Access Control (RBAC) and defined by your Dealer Profile Administrator (DPA).



Dealer Account Setup and Access

- ❑ JDLink™ Dealer organizations are created automatically when JDLink™ order is placed.
- ❑ Login into jdlink.com and test your access.
 - ❑ If you receive the message “User is not associated to an organization” see your Dealer Profile Administrator (DPA).
- ❑ Dealer must be associated with a JDLink™ organization to activate and register terminals.
- ❑ The jdlink.com and myjohndeere.com websites have specific dealer Roles & Permissions within the system. The DPA at your dealership is responsible for selecting user roles for individuals in the Role Based Access Control (RBAC) system. The DPA also manages user access to other John Deere applications.



Operations Center Customer Account Setup


1. Search for Customer Account

- ❑ Customer Account search can be performed through

JDLink™

MyJohnDeere.com

StellarSupport™



Quick List	Customers	Machines	Hardware
Last Name	<input type="text"/>	First Name	<input type="text"/>
City	<input type="text"/>	Username	<input type="text"/>

2. Identify if this is a *NEW* or *EXISTING* customer

- ❑ New customer – there are two ways to set up an account
 - Dealer creates new customer account
 - Dealer sends a request to their customer and customer creates their own account.



Operations Center Customer Account Setup: Customer Org.

- ❑ Select the Moore option  and select My Organization.
- ❑ Choose  to add a partner.

Note: The dealership must establish partnerships with the customer to complete the account setup.

- ❑ Choose Search by Organization and perform a search. If customer doesn't have an organization use the Search by Customer search feature.

Add Partner

You can add a partner organization in two ways

- ❑ If customer's information is still not found select More Options.
- ❑ The system will provide you with two options:

Option 1:

You can create a new organization.

Start by adding the organization's first member.

Option 2:

You can send an email invite to your customer.

Operations Center Customer Account Setup: Customer Org

Option 1:

- Dealer sets up profile with all customer info except:
 - Password
 - Challenge question
- Email is sent to customer for confirmation.
- Customer opens the link in the email to finish up the profile setup steps
 - Password and challenge question setup

JOHN DEERE MyJohnDeere

Create New MyJohnDeere Customer Account

To create a new customer account, start by setting up a customer profile using the fields below.

Once you provide an email address, a validation email will be sent to your customer. He/she will need to follow the instructions in that email in order to access this account and online John Deere applications.

Give this customer online account access

*Required fields:

SIGN-IN INFORMATION

Username must be at least 8 characters.

*Username

PERSONAL INFORMATION

*First Name *Last Name

Individual or Business (optional)

Individual

*Country

United States (United States)

*Address line 1

Address line 2 (optional)

*City

*State

Please Select

*Zip code

*Phone Number (At least one is required)

Mobile Work Home

*Email Address *Verify Email Address

CANCEL SUBMIT

Option 2:

- Dealer types in customer's email address and a notification is sent to the customer asking to set up an account.
- Customer logs in to [MyJohnDeere.com](https://myjohndeere.com) and selects Create New Account/New User.
- After an Organization is set up dealer or customer need to setup partnership and defining permissions
- On Add Partner page select the name of the Org that was just created and press Add Partner button.

Add Partner

Search by Organization

Search By: Organization Name Test

Add another search field Username

SEARCH

Please select the organization that you would like to add as a Partner.

Select	Administrator	Organization Name	Address
<input type="checkbox"/>		Partner One Organization	123 Main St Johnston IA 50131 United States

Didn't find what you are looking for? Try Customer Search.

Cancel ADD PARTNER



Operations Center Customer Account Setup: Partner



- ❑ Step 1: Select Dealer-Customer Relationship Type.
 - ❑ *Customer Managed*: customer does day-to-day tasks
 - ❑ *Joint Customer and Dealer Managed*: Customer and dealer share administrative tasks regarding the customer's Org, machine and people support.
 - ❑ *Dealer Managed*: Dealer solely manages customer's organization
- ❑ Step 2: Determine the Admin for the customer account and verify customer has at least started validation process.
- ❑ Step 3: What sharing permissions would you like to request?

<input checked="" type="checkbox"/> Machine Data and Services (?)	
<input checked="" type="checkbox"/> Machine Performance Data	
<input checked="" type="checkbox"/> Machine Management	
<input checked="" type="checkbox"/> Machine/Terminal Retrieval Capabilities	
<input type="checkbox"/> Production/Agronomic Data and Services (?)	
<input type="checkbox"/> Production/Agronomic/Yield Detail Data	
<input type="checkbox"/> Prescription Information	
<input type="checkbox"/> Setup Information	
<input type="checkbox"/> Send Files to Machine Capabilities	
<input type="checkbox"/> Organization Administration (?)	
<input checked="" type="checkbox"/> Administrator-Level Access to Customer Organization Account	
<input type="checkbox"/> Share Data and Create Partnerships on Behalf of Customer Organization	

Passive Permission
(defaulted to give dealer access)

Active Permissions
(requires customer action)

Activation of All JDLINK™ Hardware

Activation Steps:

1. Go to MyJohnDeere.com
2. Log into MyJohnDeere Universal Login and Select StellarSupport™



3. Select the country you are in and the Division of John Deere you are working with (Ag, C&F, JDPS)
4. Select Product Activation on the left side of the screen
5. Arrive at the My Equipment Page
6. In the JDLINK™ Tile you will need to:

a. Select the Organization customer belongs to



b. Select link to 'Manage Product'

7. Arrive at the Hardware List Page

***See next page for process continued...



Activation of All JDLink™ Hardware

JDLink

Search [] All Terminals [v] Items Per Page 10 [v]

+ Add ⊕ Activate ⌘ Transfer ⊗ Deactivate

Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
1RW8360RC[] PCMAMGC5[]	3G MTG	Ultimate 50 Hour Ultimate	2013/05/22 -	50 Hours -	New
Unregistered PCMAMGC []	3G MTG	Ultimate Ultimate 28 Day	- -	- -	New
1H0S660SLD075 PCMAMGA []	2G MTG	Ultimate	-	2014/06/09	Inactive
1RW9560[] PCMAMGA []	2G MTG	Ultimate	2011/12/05	2016/03/15	Active

Hardware Information Shown Includes:
Machine Pin, Terminal Serial Number, Hardware Type, Subscriptions, Contract Effective Date, Expiration Date, and Hardware Status

Note: Terminal subscriptions are assigned to the corresponding JDLink™ dealer account, which processed the kit order.

8. On Hardware List Page, select terminal

JDLink

+ Add ⊕ **Activate** ⌘ Transfer ⊗ Deactivate

Search [] All Terminals [v] Items Per Page 10 [v]

Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
[] []	3G MTG	Ultimate	2012/11/27	2014/08/23	New
<input checked="" type="checkbox"/> 1H0S650SEE PCMAMGC []	3G MTG	Ultimate + RDA	2013/10/23	-	New

9. Select Activate

****See next page for process continued...*

Activation of All JDLink™ Hardware

10. Select the activation available for the terminal

JDLink

+ Add **Activate** Transfer Deactivate

Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input checked="" type="checkbox"/> Unregistered PCMAMGC	3G MTG	Ultimate + RDA	2013/10/23	-	New

Available for Activation:

Ultimate + RDA ending on 2015/09/18

Cancel **Continue**

11. Select Continue

12. Terms & Conditions Pop-up box will appear. Review and select. Press Continue.

13. Review the statement and select Finish

JDLink

+ Add **Activate** Transfer Deactivate

Download Print

Services	List Price	Dealer Price
PCMAMGC		
1 Year Ultimate + RDA ending on 2015/09/18 from external order	\$0.00	\$0.00

Subtotal \$0.00 \$0.00
Tax \$0.00 \$0.00
Total \$0.00 \$0.00

Invoice & Email Information

Payment

Dealer Statement

Edit Purchases **Finish**

14. Subscription will be started.

Manage Subscriptions: Factory Install

In-Factory Activated Subscriptions:

Offered in: United States, Canada, Australia, New Zealand, Puerto Rico

- ❑ Factory Install machines receive 50 engine hour demo Ultimate+RDA subscription.

+ Add ⊕ Activate ↔ Transfer ⊗ Deactivate					
Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input type="checkbox"/> 1RW8360RC PCMAMGC52	3G MTG	Ultimate 50 Hour Ultimate	2013/05/22 -	50 Hours -	New

- ❑ A terminal will have a Temporary Subscription unless one of the three situations take place:
 1. 50 Machine Engine Hours
 2. Machine is transferred into the Customer's organization
 3. Dealer activates the Regular Subscription
- ❑ Once the regular subscription is active the Subscription End Date is updated to reflect when the regular subscription expires.

+ Add ⊕ Activate ↔ Transfer ⊗ Deactivate					
Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input type="checkbox"/> 1RW8310RP PCMAMGC	3G MTG	Ultimate	2013/03/20	2016/12/07	Active

Note: Terminal will only call in and transmit data when terminal status is active.

+ Add ⊕ Activate ↔ Transfer ⊗ Deactivate					
Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input type="checkbox"/> 1RW6150R PCMAMGA	2G MTG	Ultimate	2013/01/30	2014/07/08	Inactive

Manage Subscriptions: Field Install

- ❑ Hardware ordered in COMAR (Ag dealers): Terminals are assigned to the corresponding JDLink™ dealer account which processed the kit order.
- ❑ Hardware ordered in JDPoint (C&F Dealers): Terminals are NOT assigned to the corresponding JDLink™ Dealer account. Dealer must use the ADD button in the hardware list page of StellarSupport™ to add terminal to account.
- ❑ Subscription status is NEW.

+ Add Activate Transfer Deactivate					
Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input type="checkbox"/> 1H0S660SPC PCMAMG	3G MTG	Ultimate	2012/08/03	2014/08/23	New

- ❑ Field Install terminals receive 28-day temporary subscription.
- ❑ Subscription is activated by the dealer.

+ Add Activate Transfer Deactivate					
Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input type="checkbox"/> 1RW8360RC PCMAMGC52	3G MTG	Ultimate 50 Hour Ultimate	2013/05/22 -	-	New
<input type="checkbox"/> 1H0S660SLD075 PCMAMGA	3G MTG	Ultimate Ultimate 28 Day	- -	-	New

***See next page for process continued...



Manage Subscriptions: Field Install

Activation Steps:

1. Go to MyJohnDeere.com
2. Log into MyJohnDeere Universal Login and Select

StellarSupport™



3. Select the country you are in and the Division of John Deere you are working with (Ag, C&F, JDPS)



4. Select Product Activation
5. Select Manage Product, and select the serial number of a terminal you wish to activate

JDLink

Search All Terminals Items Per Page 10

Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input type="checkbox"/> FAKEPII PCMAM	2G MTG	Select + RDA 28 Day	2012/08/20	-	New
<input checked="" type="checkbox"/> 123456TEST PCMAMGA737684	2G MTG	Select	2013/09/30	2014/09/30	New

6. Select Activate

Install hardware after Activations are complete.



Activation Process: Factory Installed, Non-Factory Activated Subscriptions

All Countries Except: United States, Canada, Australia, Mexico, New Zealand, Puerto Rico and Russia.

- ❑ A 28 Day temporary subscription will be added to each terminal. You must go to StellarSupport.com to activate the service.
- ❑ Choose the terminals you wish to activate and select the Activate button.
- ❑ You will have the option to activate either the temporary or the purchased subscription. Choose the subscription you wish to activate and select Continue.

Note: If you choose to activate the purchased subscription, the temporary subscription will be removed. You will not be able to activate the temporary subscription at a later date.

- ❑ When the machine is transferred to a customer account, the temporary subscription is deactivated and the regular subscription purchased with the machine is automatically activated.
- ❑ If the temporary subscription is allowed to expire, the service will turn off. You must return to StellarSupport.com and repeat the steps above to activate the purchased subscription.

Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input checked="" type="checkbox"/> 1N04830XKD0028447 PCMAMGC521301	3G MTG	-	-	-	New
Available for Activation:					
<input checked="" type="radio"/> Ultimate 28 Day Subscription ending on 2014/07/08					
<input type="radio"/> Ultimate Subscription ending on 2015/06/10 (Cancel Temporary License)					




Activation Process: Field Kit Activations

All Countries Except: Mexico and Russia.

- ❑ A 28 Day temporary subscription will be added to each terminal. You must go to StellarSupport.com to activate the service.
- ❑ Choose the terminals you wish to activate and select the Activate button.
- ❑ You will have the option to activate either the temporary or the purchased subscription. Choose the subscription you wish to activate and select Continue.
- ❑ When the machine is transferred to a customer account, the temporary subscription is deactivated and the license purchased with the machine is automatically activated.
 - ❑ If the temporary subscription is allowed to expire, the service will turn off. You must return to StellarSupport.com and repeat the steps above to activate the purchased subscription.
 - ❑ If the terminal was purchased without a subscription, please see the Purchase Subscription section for steps to activate service after the temporary subscription has expired.

Serial Number	Type	Subscription	Contract Effective	Subscription Expiration	Status
<input checked="" type="checkbox"/> 1N04830XKD0028447 PCMAMGC521301	3G MTG	-	-	-	New
Available for Activation:					
<input checked="" type="radio"/> Ultimate 28 Day Subscription ending on 2014/07/08					
<input type="radio"/> Ultimate Subscription ending on 2015/06/10 (Cancel Temporary License)					



Activation Process: Non-Factory Activated Subscriptions & Field Kits

For Mexico and Russia.

- ❑ JDLink™ subscriptions are being offered as a direct promotion from John Deere to the end customer and must be activated by an Admin in the Organization who is accepting the offer.
- ❑ Subscriptions in these markets are not transferable. Do not activate promotional subscription until it is in the final Organization or the promotional subscription will be cancelled.
- ❑ Once the terminals are in customer's organization the non-activated temporary subscription will be in a New state. The customer then will choose terminals they wish to activate and select Activate button.
- ❑ Either temporary or promotional subscription can be activated. Choose subscription you wish to activate and enter full Order number from original hardware purchase, then select Continue.

Serial Number	Type	Subscription	Contract Effective	Subscription Expiration
<input checked="" type="checkbox"/> 1N04830XKD0028447 PCMAMGC521301	3G MTG	-	-	-


Available for Activation:

- Ultimate 28 Day Subscription ending on 2014/07/08
- Ultimate Subscription ending on 2015/06/10 (Cancel Temporary License)

Order Number: 06562345

Temporary Subscription

Purchased Subscription



***See next page for process continued...

Activation Process: Non-Factory Activated Subscriptions & Field Kits

For Mexico and Russia.

Activating Temporary Subscription and then Regular Subscription.

- ❑ A 28 Day temporary subscription will be added to each terminal to allow Dealer time for training. After the promotion has been accepted.

Note: When the terminal is in the Dealer's account the dealer is able to activate temporary subscription only.

- ❑ Dealer activates Temporary Subscription
 - ❑ You must transfer terminal to customer's account and activate the promotional subscription within 28 days or service will shut off.
- ❑ Dealer transfers terminal in JDLink™ to the customer org.
- ❑ Customer activates promotional subscription.

Activating Promotional Subscription Only:

- ❑ Dealer transfers terminal in JDLink™ to customer org
- ❑ Customer activates promotional subscription
 - ❑ If you choose to activate promotional subscription immediately, the temporary subscription option will be removed. You will not be able to activate Temporary subscription at a later date.



Hardware Installation General Information

Important criteria for JDLink™ to communicate and collect data

- ❑ Device requires a power supply - MTG 12 or 24 Volts
- ❑ Cellular Communication – activated SIM card (occurs automatically through subscription activation process)
 - ❑ Optional satellite module is available for communication in areas with no cell coverage which utilizes a separate satellite antenna.
- ❑ Assign Terminal to Equipment (occurs automatically for JDLink™ Ultimate).
- ❑ JDLink™ antenna requires a clear view to the sky to acquire GPS signal for location services.
 - ❑ Ex: Location services may not function properly when equipment is in a metal building.



Install Hardware: Ultimate Field Installation

- ❑ Install JDLINK™ terminal and harnessing on machine.



- ❑ Allow the machine to run for 5—10 min. after installation. MTG placing a successful call allows for terminal to auto register.
- ❑ Log in to jdlink.com
- ❑ Go to Admin/Settings tab
- ❑ Select Terminal Setup button
- ❑ Verify terminal and machine are registered.

Terminal ID	Comm.	Type	License	Registration Status	Last Call In
Terminal ID: PCMAMGC504090		MTG	Ultimate	Registered 05/10/2013	 12:04 PM 11/14/2013 (2522hours ago)

NOTE: For assistance with installation, see Operator's Manual provided with JDLINK™ field kit or JDLINK™ Technical Manual in Service ADVISOR™.



Install Hardware: Field Installation (Select, Locate, Express)

- ❑ Install JDLINK™ terminal and harnessing on machine.
- ❑ Log into jdlink.com.
- ❑ Go to Admin/Settings tab.
- ❑ Select Terminal Setup button.
- ❑ Select the newly installed Terminal ID in the list.
- ❑ Select Assign Terminal to Equipment button.
- ❑ If inactive machine exists in system, select machine from Pick from Equipment list, then select Save and Close.

The screenshot displays the JDLink™ Admin/Settings interface. The 'Terminal Setup' tab is selected, showing a list of terminals. The 'Assign Terminal to Equipment' button is highlighted with a red circle. The interface includes a search bar for 'Equipment ID', a table of terminal details, and a 'Call History' section.

New	Equipment ID	Terminal ID	Comm	Type	License	Registration Status	Last Call In
	[REDACTED]	[REDACTED]		MTG			

Equipment Details

EQUIPMENT ID	MAKE	Type	MODEL
[REDACTED]	John Deere	JDLINK	MTG
PIN	GPS ANTENNA		
[REDACTED]	OK		

Terminal Details

LICENSE TYPE	Cell Id	JDLINK TERMINAL	DISPLAY ID
Select	[REDACTED]	PCMAV	PCGU
REGISTRATION STATUS	REGISTRATION DATE	COMAR NUMBER	
Registered	03/29/2012		

Call History

7:41 PM	08/15/2014	(1412hours ago)
9:20 PM	08/14/2014	(1435hours ago)
8:20 PM	08/14/2014	(1436hours ago)
7:20 PM	08/14/2014	(1437hours ago)
6:20 PM	08/14/2014	(1438hours ago)
6:08 PM	08/14/2014	(1438hours ago)
5:20 PM	08/14/2014	

Buttons: TRANSFER TERMINAL, ASSIGN TERMINAL TO EQUIPMENT, UPDATE EQUIPMENT INFORMATION, CANCEL, SAVE & CLOSE (highlighted).



Install Hardware: Field Installation (Select, Locate, Express)

- ❑ If machine does not exist in list, select Add Equipment.
- ❑ It is important to use a unique Machine Name so different machines are not mistaken. Use the machine Personal Identification Number (PIN) as a unique machine identifier.
- ❑ Machine Make/Type/Model automatically populates if system recognizes a machines PIN. If machine PIN is not recognized, user can enter information manually.
- ❑ If needed fill in machine Make/Type/Model information.
- ❑ When all information has been entered, select Save and Close button.
- ❑ The terminal will be in a Pending Registration state until terminal has placed a successful cellular call. Once cellular communication has completed, the terminal will display as registered and be able to start collecting data.

NOTE: For assistance with installation, see Operator's Manual provided with JDLINK™ field kit or JDLINK™ Technical Manual in Service ADVISOR™.



Terminal Transfers

There are two ways to transfer terminals:

MyJohnDeere - Operations Center

- Log in to [MyJohnDeere.com](https://myjohndeere.com)
- Select Operations Center and click More button
- Select a terminal by placing a check in the box next to Terminal ID



<input checked="" type="checkbox"/>	Terminal ID	Type	Machine Details	Capabilities	Subscription	Owner	Third Party
<input checked="" type="checkbox"/>	PCMAMGA	MTG			Ultimate		


- Transfer terminal button 
- Select an Organization>Review>Transfer

JDLINK™ Website

- Log in to [Jdlink.com](https://jdlink.com)
- Go to Admin & Settings
- Select Terminal Setup, then choose terminal and Select Transfer
- Select Terminal Transfer and search for the customer
 - Note: If Incomplete Partnership is displayed, see Setup Customer Account.*
- Select Customer and click Transfer

Terminal Transfer: Operations Center

- ❑ Log in to MyJohnDeere.com and select Operations Center
- ❑ Open the Moore option and select Terminals




- ❑ Check the terminal you wish to transfer and select the Terminal Transfer button

Terminals

Terminal ID	Type	Machine Details	Capabilities	Subscription	Owner	Third Party
<input checked="" type="checkbox"/> PCMAMGA72081	MTG	Test Machine 3 RWS330P042819 JOHN DEERE 8330		Select <i>machine</i>	Dealer Demo Org	
<input type="checkbox"/> PCMAMGA765947	MTG	Test Machine 2 H09650691483 JOHN DEERE 9650 STS		Ultimate	Dealer Demo Org	
<input type="checkbox"/> PCMAMGA770807	MTG	Test Machine 1 1RW7230RVA000115 JOHN DEERE 7230R		Select	Dealer Demo Org	
<input type="checkbox"/> UTGCU5TDEM012	UTG	Customer Machine(Transferred) DEM012345678912 JOHN DEERE 8330			Customer Demo Org	

Terminal Transfer: Operations Center

- ❑ Select the Organization Name and press Review



- ❑ Then select the Transfer button



Terminal Transfer: JDLink™

- ❑ Log in to JDLink.com and select ADMIN/SETTINGS tab

The screenshot shows the JDLink™ ADMIN/SETTINGS interface. The 'ADMIN/SETTINGS' tab is highlighted with a red circle. Below it, the 'MACHINES' section shows a list of machines, with 'Gone Fishing BRB' selected. The main area displays a map, an alerts table, and an engine hours table.

Type	Machine	Name	Date	Ackno...	A.
Gone Fi...	RED	HL...	03/09/2014 5:47 pm	Ackno...	L.
Gone Fi...	RED	PT...	03/02/2014 5:14 pm		L.
Gone Fi...	RED	PT...	03/02/2014 5:18 pm		L.
Gone Fi...	RED	PT...	03/02/2014 6:13 pm		L.
Gone Fi...	RED	PT...	03/16/2014 5:42 pm		L.
Gone Fi...	RED	PT...	04/01/2014 6:25 am	Ackno...	L.

Machine	Time Fil...	Engine Hours	Last Reading
Gone Fishing BRB	132.9	284.7	07/16/2014 1:59 PM
Total	132.9	284.7	

- ❑ Choose Terminal Setup and select a terminal you would like to transfer

The screenshot shows the JDLink™ Terminal Setup interface. The 'Terminal Setup' tab is selected. A table lists terminals with columns for Equipment ID, Terminal ID, Comm, Type, License, Registration Status, and Last Call In. The terminal with ID PCMAAMGA701652 is highlighted in yellow and circled in red.

New	Equipment ID	Terminal ID	Comm	Type	License	Registration Status	Last Call In
		Terminal ID: PCMAAMG617099 Display ID: PCGUZUD480320		MTG	Ultimate	Unregistered	7:25 AM 07/15/2014 (51 hours ago)
		Terminal ID: PCMAAMG615991 Display ID: PCGUZUD482018		MTG	Ultimate	Unregistered	2:22 PM 07/10/2014 (164 hours ago)
		Terminal ID: PCMAAMGA701652		MTG	Ultimate	Unregistered 07/18/2012	8:09 AM 12/04/2012 (1416 hours ago)
		Terminal ID: PCMAAMGA400170		MTG	Ultimate	Unregistered 10/15/2010	7:33 PM 06/02/2011 (2734 hours ago)
		Terminal ID: PCMAAMG616763		MTG	Ultimate	Unregistered	2:40 AM 07/14/2014 (79 hours ago)
		Terminal ID: PCMAAMG606843 Display ID: PCGUZUC408594		MTG	Ultimate	Unregistered 03/26/2013	12:16 PM 05/14/2014 (153 hours ago)
		Terminal ID: PCMAAMGA715038		MTG	Ultimate	Unregistered 02/02/2013	12:12 PM 06/19/2014 (670 hours ago)
		Terminal ID: PCMAAMG6236647				Unregistered	



Terminal Transfer: JDLink™


- ❑ Select Transfer Terminal

The screenshot shows the JDLink terminal management interface. On the left, under 'Terminal Details', the 'TRANSFER TERMINAL' option is circled in red. Other options include 'ASSIGN TERMINAL TO EQUIPMENT' and 'UPDATE EQUIPMENT INFORMATION'. The 'Equipment Details' section shows fields for EQUIPMENT ID, MAKE, Type, and MODEL. The 'Terminal Details' section shows fields for LICENSE TYPE (Ultimate), SATELLITE ID, REGISTRATION STATUS (Unregistered), REGISTRATION DATE (07/18/2012), COMAR NUMBER, and JDLINK TERMINAL (PCMAMGA701652). On the right, there is a 'Call History' section with a table and a 'Call Now' button. At the bottom, there are 'CANCEL' and 'SAVE & CLOSE' buttons.


- ❑ Search for the Customer whose profile the terminal will be transferred to
- ❑ Select Customer and press the Transfer button

The screenshot shows the 'Transfer Terminal' search form. It has a 'Search' label on the left. The form is divided into two sections: 'By Location' and 'By ID'. The 'By Location' section includes fields for *Country (UNITED STATES), City (Urbandale), State (Iowa), and Zip Code (503222). The 'By ID' section includes a field for *Dealer ID. A 'Search' button is located on the right. At the bottom, there are 'CANCEL' and 'TRANSFER' buttons, with the 'TRANSFER' button circled in red.

Resources



Pathways: DTAC Solutions & Data Administration Guidelines



JDLINK™: Online Help



StellarSupport™: JDLINK™ Operators Manual & Installation Instructions



Customer Event Materials Website: JDLINK™ Value Guide





JOHN DEERE JDLink™ Setup GUIDE

Unpublished work © 2013 Deere & Company. All Worldwide Rights Reserved.
THIS MATERIAL IS THE PROPERTY OF DEERE & COMPANY.
ALL USE, ALTERATIONS, DISCLOSURE, DISSEMINATION AND/OR REPRODUCTION
NOT SPECIFICALLY AUTHORIZED BY DEERE & COMPANY IS PROHIBITED.

